
Trade Waste Solutions

AS3495
75136


Stainless Steel Adjustable Bottle Trap Spare Parts

TRAP-BOTTLE



1	Plastic inner tube	TRAP-P-INTUBE
2	Inlet tube 32mm dia x 144mm L. 304 grade S/S	
3	Rubber seal to suit inlet tube to waste.	
4	60mm diameter nut for waste outlet connection for bottle trap. 304 grade S/S	TRAP-P-60NUT
5	52mm diameter nut for inlet tube connection to bottle trap. 304 grade S/S	TRAP-P-52NUT
6	Rubber seal to suit outlet tube for connection to bottle trap.	TRAP-P-GASKET
7	47mm diameter nut for outlet tube connection to bottle trap. 304 grade S/S	TRAP-P-47NUT
8	Outlet tube 32mm diameter x 300mm L. 304 grade S/S	TRAP-P-PTUBE
9	Domed cover For bottle trap. 70mm diameter x 10mmH. 304 grade S/S	TRAP-P-DOMECOVER
10	40mm rubber keyseal	TRAP-P-40KEE
11	50mm rubber keyseal	TRAP-P-50KEE

TRAP-SBOTTLE



1	Plastic inner tube	TRAP-P-INTUBE
2	Inlet tube 32mm dia x 144mm L. 304 grade S/S	
3	Rubber seal to suit inlet tube to waste.	
4	60mm diameter nut for waste outlet connection for bottle trap. 304 grade S/S	TRAP-P-60NUT
5	52mm diameter nut for inlet tube connection to bottle trap. 304 grade S/S	TRAP-P-52NUT
6	Rubber seal to suit outlet tube for connection to bottle trap.	TRAP-P-GASKET
7	47mm diameter nut for outlet tube connection to bottle trap. 304 grade S/S	TRAP-P-47NUT
8	Outlet tube 32mm diameter x 300mm L x 750mm L. 304 grade S/S	TRAP-P-STUBE
9	Domed cover for bottle trap. 70mm diameter x 10mm H. 304 grade S/S	TRAP-P-DOMECOVER
10	40mm rubber keyseal	TRAP-P-40KEE
11	50mm rubber keyseal	TRAP-P-50KEE