
















Exploded diagram and spare parts list

F234-A

Waring Ice Crusher - 2.4Ltr	1		Top Cover
Waring Ice Crusher - 2.4Ltr	2		Switch (Current Production)
Waring Ice Crusher - 2.4Ltr	2		Switch (Older Version)
Waring Ice Crusher - 2.4Ltr	3		Enclosure Wrap (Punched)
Waring Ice Crusher - 2.4Ltr	3		Enclosure Wrap
Waring Ice Crusher - 2.4Ltr	4		Bottom Cover
Waring Ice Crusher - 2.4Ltr	5		Cap Plug
Waring Ice Crusher - 2.4Ltr	6		Screw
Waring Ice Crusher - 2.4Ltr	7		Cord Set
Waring Ice Crusher - 2.4Ltr	8		Base (Coated)
Waring Ice Crusher - 2.4Ltr	9		Strain Relief
Waring Ice Crusher - 2.4Ltr	10		Screw
Waring Ice Crusher - 2.4Ltr	11		Washer
Waring Ice Crusher - 2.4Ltr	12		Screw
Waring Ice Crusher - 2.4Ltr	13		Splash Guard
Waring Ice Crusher - 2.4Ltr	13		Retention Panel Clip
Waring Ice Crusher - 2.4Ltr	14		Motor Assy
Waring Ice Crusher - 2.4Ltr	15		Middle Spacer
Waring Ice Crusher - 2.4Ltr	16		Blade Support Spacer
Waring Ice Crusher - 2.4Ltr	17		Right Hand Housing
Waring Ice Crusher - 2.4Ltr	18		Left Hand Housing
Waring Ice Crusher - 2.4Ltr	19		Screw
Waring Ice Crusher - 2.4Ltr	20		Spring Pin
Waring Ice Crusher - 2.4Ltr	21		End Spacer
Waring Ice Crusher - 2.4Ltr	22		No.3 Blade
Waring Ice Crusher - 2.4Ltr	23		Fixed Blade
Waring Ice Crusher - 2.4Ltr	24		No.2 Blade
Waring Ice Crusher - 2.4Ltr	25		No.1 Blade
Waring Ice Crusher - 2.4Ltr	26		Screw
Waring Ice Crusher - 2.4Ltr	27		Lead
Waring Ice Crusher - 2.4Ltr	28		Cable Tie
Waring Ice Crusher - 2.4Ltr	29		Washer
Waring Ice Crusher - 2.4Ltr	30		Cable Clamp
Waring Ice Crusher - 2.4Ltr	31		Screw
Waring Ice Crusher - 2.4Ltr	32		Bracker
Waring Ice Crusher - 2.4Ltr	33		Funnel
Waring Ice Crusher - 2.4Ltr	34		Bowl (Plastic)