



Exploded diagram and spare parts list (CC039-A)

Machine	Explode	Code	Description
CC039-A - Apuro Crepe Maker - 2.9kW	1		Cast Iron Heating Plate
CC039-A - Apuro Crepe Maker - 2.9kW	2		Heating Element
CC039-A - Apuro Crepe Maker - 2.9kW	3		Hardware Assembly
CC039-A - Apuro Crepe Maker - 2.9kW	4		Insulation Cotton
CC039-A - Apuro Crepe Maker - 2.9kW	5		Mica Plate
CC039-A - Apuro Crepe Maker - 2.9kW	6		Insulate Plate
CC039-A - Apuro Crepe Maker - 2.9kW	7	AC692	Thermal Cut Out
CC039-A - Apuro Crepe Maker - 2.9kW	8		Stick
CC039-A - Apuro Crepe Maker - 2.9kW	9		Bushing
CC039-A - Apuro Crepe Maker - 2.9kW	10		Plug & Lead
CC039-A - Apuro Crepe Maker - 2.9kW	11		Reset Cap
CC039-A - Apuro Crepe Maker - 2.9kW	12		The Breaker Fixed Plate Assembly
CC039-A - Apuro Crepe Maker - 2.9kW	13		Main Body Assy
CC039-A - Apuro Crepe Maker - 2.9kW	14		Hardware Assembly
CC039-A - Apuro Crepe Maker - 2.9kW	15		Handle
CC039-A - Apuro Crepe Maker - 2.9kW	16		Bottom Plate
CC039-A - Apuro Crepe Maker - 2.9kW	17	AC689	Feet
CC039-A - Apuro Crepe Maker - 2.9kW	18	N125	Thermostat
CC039-A - Apuro Crepe Maker - 2.9kW	19	N129	Dial
CC039-A - Apuro Crepe Maker - 2.9kW	20	N486	Indicator Light
CC039-A - Apuro Crepe Maker - 2.9kW	N/A	AC694	Wooden Kit - Accessories