




















Exploded diagram and spare parts list

GF422-A

Machine	Explode	Code	Description
Waring Blender Variable Speed - 4Ltr	1		Hot Blending Outer Lid
Waring Blender Variable Speed - 4Ltr	2		Plastic Outer Lid Gasket
Waring Blender Variable Speed - 4Ltr	3		Hot Blending Lid Baffle Cup
Waring Blender Variable Speed - 4Ltr	4		Cap Nut
Waring Blender Variable Speed - 4Ltr	5		Flat St/St Washer
Waring Blender Variable Speed - 4Ltr	6		Blade
Waring Blender Variable Speed - 4Ltr	7		"O" Ring
Waring Blender Variable Speed - 4Ltr	8		Bearing Cap
Waring Blender Variable Speed - 4Ltr	9		Small V Ring
Waring Blender Variable Speed - 4Ltr	10		Bearing holder
Waring Blender Variable Speed - 4Ltr	11		Washer
Waring Blender Variable Speed - 4Ltr	12		Bearing
Waring Blender Variable Speed - 4Ltr	13		Spacer
Waring Blender Variable Speed - 4Ltr	14		Spring Washer
Waring Blender Variable Speed - 4Ltr	15		Retaining Ring
Waring Blender Variable Speed - 4Ltr	16		Large V Ring
Waring Blender Variable Speed - 4Ltr	17		Drive Shaft
Waring Blender Variable Speed - 4Ltr	18		Key
Waring Blender Variable Speed - 4Ltr	19		Cover Insert
Waring Blender Variable Speed - 4Ltr	20		Outer Lid
Waring Blender Variable Speed - 4Ltr	21		Latch Wire
Waring Blender Variable Speed - 4Ltr	22		Bracket Assy
Waring Blender Variable Speed - 4Ltr	23		Container With Guard (Units After 12/02/2015)
Waring Blender Variable Speed - 4Ltr	23		Double Handed Container
Waring Blender Variable Speed - 4Ltr	24	AB760	Blending Assy
Waring Blender Variable Speed - 4Ltr	25		Container Base Gasket
Waring Blender Variable Speed - 4Ltr	26		Container Support
Waring Blender Variable Speed - 4Ltr	27		Lock Nut
Waring Blender Variable Speed - 4Ltr	28	AE731	Coupling
Waring Blender Variable Speed - 4Ltr	29		Jar Pad
Waring Blender Variable Speed - 4Ltr	30		Top Housing
Waring Blender Variable Speed - 4Ltr	31	AE733	Control Panel Assy
Waring Blender Variable Speed - 4Ltr	32		Control Panel Rear
Waring Blender Variable Speed - 4Ltr	33		Screw
Waring Blender Variable Speed - 4Ltr	34		Control Panel Baffle
Waring Blender Variable Speed - 4Ltr	35		Washer
Waring Blender Variable Speed - 4Ltr	36		Screw
Waring Blender Variable Speed - 4Ltr	37	AE734	Motor With Sensor
Waring Blender Variable Speed - 4Ltr	38		Screen

Exploded diagram and spare parts list

GF422-A

Waring Blender Variable Speed - 4Ltr	39		Screw
Waring Blender Variable Speed - 4Ltr	40		Cable Tie
Waring Blender Variable Speed - 4Ltr	41		Baffle
Waring Blender Variable Speed - 4Ltr	42		Filter & Bracket Assy
Waring Blender Variable Speed - 4Ltr	43		Screw
Waring Blender Variable Speed - 4Ltr	44		Brown Lead
Waring Blender Variable Speed - 4Ltr	45		Blue Lead
Waring Blender Variable Speed - 4Ltr	46		Green-Yellow Ground Lead
Waring Blender Variable Speed - 4Ltr	47		Strain Relief
Waring Blender Variable Speed - 4Ltr	48		Cordset
Waring Blender Variable Speed - 4Ltr	49		Ground Washer
Waring Blender Variable Speed - 4Ltr	50		Ground Screw
Waring Blender Variable Speed - 4Ltr	51		Bottom Housing
Waring Blender Variable Speed - 4Ltr	52		Washer
Waring Blender Variable Speed - 4Ltr	53		Screw
Waring Blender Variable Speed - 4Ltr	54		Foot
Waring Blender Variable Speed - 4Ltr	55		Washer
Waring Blender Variable Speed - 4Ltr	56		Screw
Waring Blender Variable Speed - 4Ltr	N/A	AE738	Brush & Spring Assy
Waring Blender Variable Speed - 4Ltr	N/A		Brush Cap