



503357 Kit *Parts Included*

















Power Pack Coupling Tool

Shaft Coupling Tool



To use the 503357 kit the bottom of your Power Pack must look like this.



Machine	Explode	Code	Description
Waring Variable Stick Blender	1	AC992-A	WSBK Power Pack
Waring Variable Stick Blender	2		Hole Plug
Waring Variable Stick Blender	2a		Hole Plug
Waring Variable Stick Blender	3		Screw
Waring Variable Stick Blender	4		Name Plate Panel
Waring Variable Stick Blender	5		Screw
Waring Variable Stick Blender	6		Hold Plug
Waring Variable Stick Blender	7		Screw
Waring Variable Stick Blender	8		Screw
Waring Variable Stick Blender	9		Screw
Waring Variable Stick Blender	10		Screw
Waring Variable Stick Blender	11		Housing Cover
Waring Variable Stick Blender	12		12"Shaft Assy - With Blade
Waring Variable Stick Blender	13		14"Shaft Assy - With Blade
Waring Variable Stick Blender	14		16"Shaft Assy - With Blade
Waring Variable Stick Blender	15		18"Shaft Assy - With Blade
Waring Variable Stick Blender	16		21"Shaft Assy - With Blade
Waring Variable Stick Blender	503281	AD262	PCB Assy
Waring Variable Stick Blender	503357	AC147	Coupling Kit

Internal Component

