

















Machine	Explode	Code	Description
J300-A Apuro Rice Cooker - 6Ltr	1		Cover Set
J300-A Apuro Rice Cooker - 6Ltr	2	AC393	Inner Pot
J300-A Apuro Rice Cooker - 6Ltr	3	AC381	Magnetic Thermal Limiter
J300-A Apuro Rice Cooker - 6Ltr	4		Heating Element
J300-A Apuro Rice Cooker - 6Ltr	5		Liner Bowl
J300-A Apuro Rice Cooker - 6Ltr	6		Heating Ring
J300-A Apuro Rice Cooker - 6Ltr	7		Ceramic Terminal(Three Terminal)
J300-A Apuro Rice Cooker - 6Ltr	8	AG993	185°C Thermostat
J300-A Apuro Rice Cooker - 6Ltr	9		Electric Switch
J300-A Apuro Rice Cooker - 6Ltr	10		216°C Fuse
J300-A Apuro Rice Cooker - 6Ltr	11	AF794	68°C Thermostat
J300-A Apuro Rice Cooker - 6Ltr	12		Keep Warm Cotton
J300-A Apuro Rice Cooker - 6Ltr	13		Water Collect
J300-A Apuro Rice Cooker - 6Ltr	14		Pot Body Fixed Ring
J300-A Apuro Rice Cooker - 6Ltr	15		Outer Body
J300-A Apuro Rice Cooker - 6Ltr	16		Main Switch Set
J300-A Apuro Rice Cooker - 6Ltr	17		Bracket
J300-A Apuro Rice Cooker - 6Ltr	18		Bottom
J300-A Apuro Rice Cooker - 6Ltr	19		Bottom Cover
J300-A Apuro Rice Cooker - 6Ltr	20		Power Cord-AU
J300-A Apuro Rice Cooker - 6Ltr	21	AC641	Feet
J300-A Apuro Rice Cooker - 6Ltr	22	AC643	Rice Fork
J300-A Apuro Rice Cooker - 6Ltr	N/A	AC644	Rice Paddle
J300-A Apuro Rice Cooker - 6Ltr	N/A	AC645	Measuring Cup/800ML
J300-A Apuro Rice Cooker - 6Ltr	N/A		Measuring Cup/180ML
J300-A Apuro Rice Cooker - 6Ltr	N/A	AJ167	Rice Mat