


apuro

Food Steamer Instruction manual



**Model:
CL205-A**

Safety Tips

- Position on a flat, stable surface.
 - A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
 - Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - Fire Precautions
 - Wiring Regulations
 - Building Regulations
 - Ensure the location for the appliance can support its weight when full.
 - DO NOT immerse the appliance in water.
 - DO NOT leave the machine unattended during operation.
 - DO NOT operate this appliance when less than one third full.
 - DO NOT touch the outer surfaces of the appliance. They become hot during use.
- 
- Suitable for indoor use only.
 - Always switch off and disconnect the power supply to the appliance when not in use.
 - Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
 - If the power cord is damaged, it must be replaced by an Apuro agent or a recommended qualified technician in order to avoid a hazard.
 - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
 - Apuro recommend that this appliance is PAT tested on an annual basis to ensure the product remains safe.

Product Description

- CL205-A - 6 litre Stainless Steel Steamer

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your Apuro product.

Pack Contents

The following is included:

- Apuro Steamer and lid
- Steamer Basket
- Instruction Manual

Apuro prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your Apuro dealer immediately.


Operation

1. Remove the appliance from the packaging. Make sure that all protective plastic film and plastic coatings are thoroughly removed from all surfaces.



Note: Before using for the first time, clean the interior of the appliance and all parts in warm soapy water, then rinse thoroughly.

2. Ensure the Temperature Control knob is set to 'OFF'.
3. Remove the lid and fill the appliance to at least half of its capacity. Do not exceed the Max fill line.
4. Place the food to be steamed in the removable stainless steel basket.
5. Replace the lid.
6. Connect to the mains power supply and turn the temperature control knob on. The power indicator light illuminates.
7. Set the Temperature Control knob to maximum to boil the water. The power indicator light illuminates and the appliance heats the water.



- When not steaming food the temperature control knob can be lowered to keep the water warm and reduce heating times.



WARNING: If the Temperature Control Knob is set to maximum then the appliance will constantly heat the water until the Temperature Control Knob is turned Off or the temperature is reduced.

Thermal Cut-Out Reset

This appliance is fitted with a Thermal Cut-Out safety feature. Should the temperature exceed safe levels the appliance will automatically cut power.

The Safety Cut-out switch resets automatically. To reset the appliance:

- Disconnect from mains power supply, empty the appliance and allow to cool.
- The appliance is now reset and can be used as normal.

Cleaning, Care and Maintenance

- Always turn off and disconnect the appliance from the power supply before cleaning.
- Use soapy water and a damp cloth to clean the exterior of the appliance.
- Dry thoroughly after cleaning.

De-scaling

In hard water areas lime scale can build up within the appliance after prolonged use. To de-scale the appliance:

- Pour a solution of de-scaler and water into the appliance.
- Brush the interior gently with a soft bristled brush.
- Discard the solution collected in the jug.
- Fill the appliance with clean water and turn back On to flush out the system. Flush out the system thoroughly to remove any de-scaler residue.
- The appliance is now ready for use.



**Note: Use a suitable de-scaler and always follow the instructions on the container.
Apuro recommend that this appliance is de-scaled every month or more frequently in hard water areas.**

Troubleshooting

Fault	Probable Cause	Solution
The unit is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug and lead are damaged	Call Apuro agent or qualified technician
	Fuse in the plug has blown	Replace the plug fuse
	Power supply	Check power supply
	Internal wiring fault	Call Apuro agent or qualified technician
	Thermal fuse has activated	Reset Thermal fuse (see "Thermal Cut-Out Reset" on page 4)
Power Indicator light comes on but water does not reach temperature	Thermostat fault	Call Apuro agent or qualified technician

Technical Specifications

Model	Voltage	Power	Current	Capacity	Weight	Dimensions H x W x D mm
CL205-A	220-240V 50/60Hz	1000W	4.4A	6 litres	10.2kg	305 x 400 x 335

Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



APURO parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.



APURO products have been approved to carry the following symbol:



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of APURO.

Every effort is made to ensure all details are correct at the time of going to press, however, APURO reserve the right to change specifications without notice.

DECLARATION OF CONFORMITY

Equipment Type	Food Steamer
Model	CL205-A
Legislation	Electrical Safety Electromagnetic Compatibility
Standards	AS/NZS 60335-1:2012 +A1:2012 +A2:20104 AS/NZS 60335-2-15:2013 AS/NZS CISPR 14.1:2013
Producer Name	Apuro
Producer Address	15 Badgally Road, Campbelltown, NSW 2560

I, the undersigned, hereby declare that the equipment specified above conforms to the above Legislation and Standard(s).

Date	5th June 2017
Signature	
Full Name	Ashley Hooper
Position	Technical & Quality Manager/ Responsible Supplier



CL205-A_A5_v1_170606